

MOTORBIKE SUITS: MAN


EURO	44	46	48	50	52	54	56	58	60	62	64
ALPHA	S	S	M	M	L	L	XL	XL	XXL	XXXL	XXXXL
USA-UK	34	36	38	40	42	44	46	48	50	52	54
CHEST	86-90	90-94	94-98	98-102	102-106	106-110	110-114	114-118	118-122	122-126	126-130
ARM	56-57	57-58	58-59	59-60	60-61	61-62	62-63	62-63	63-64	63-64	64-65
NECK	36.5-37.5	37.5-38.5	38.5-39.5	39.5-40.5	40.5-41.5	41.5-42.5	42.5-43.5	43.5-44.5	44.5-45.5	45.5-46.5	46.5-47.5
WAIST	74-78	78-82	82-86	86-90	90-94	94-98	98-102	102-106	106-110	110-114	114-118
HIPS	88-92	92-96	96-100	100-104	104-108	108-112	112-116	116-120	120-124	124-128	128-132
INSEAM	77-79	79-80	80-82	82-83	83-84	84-85	85-86	86-87	87-88	87-88	88-89

HOW TO MEASURE YOURSELF

CHEST

Circumference of the chest

The circumference of the chest is the maximum measurement taken around the chest when standing upright and breathing normally. The tape measure is passed around the chest at the level of the shoulder blades, below the armpits.



ARM

Sleeve length


This is the distance between the outside of the shoulder (humerus) and the wrist when the arm is relaxed.



NECK

Circumference of the neck


The circumference of the neck is measured about 2 cm below the Adam's apple at the seventh cervical vertebra.



WAIST


Circumference of the waist

The circumference of the waist is measured by passing the tape measure on the waistline between the ribs and the pelvis just above the hip bones. Take the measurement when standing upright and breathing normally with the abdomen relaxed.

**HIPS**


Circumference of the hips

The circumference of the hips is measured horizontally around the part of the pelvis that protrudes most.

**INSEAM**

Inner Leg Measurement

The distance between the lowest part of the trunk and the soles of the feet measured when standing upright with the feet slightly apart and the weight of the body evenly distributed on both legs.


**MOTORBIKE SUITS: WOMAN**

EURO	38	40	42	44	46	48	50	52	54
ALPHA	XXS	XS	S	M	M	L	XL	XL	XXL
USA-UK	0	2	4	6	8	10	12	14	16
CHEST	72-76	76-80	80-84	84-88	88-92	92-96	96-100	100-104	104-108
ARM	51-52	52-54	54-55	55-57	57-58	58-59	59-60	60-61	60-61
WAIST	56-60	60-64	64-68	68-72	72-76	76-80	80-84	84-88	88-92
HIPS	82-86	86-90	90-94	94-98	98-102	102-106	106-110	110-114	114-118
INSEAM	73-75	75-76	76-78	78-79	79-80	80-81	81-82	81-82	81-82

HOW TO MEASURE YOURSELF

CHEST

Circumference of the chest



The circumference of the chest is the maximum measurement taken around the chest when standing upright and breathing normally. The tape measure is passed around the chest at the level of the shoulder blades, below the armpits.

ARM


Sleeve length



This is the distance between the outside of the shoulder (humerus) and the wrist when the arm is relaxed.

WAIST


Circumference of the waist



The circumference of the waist is measured by passing the tape measure on the waistline between the ribs and the pelvis just above the hip bones. Take the measurement when standing upright and breathing normally with the abdomen relaxed.

HIPS


Circumference of the hips



The circumference of the hips is measured horizontally around the part of the pelvis that protrudes most.

INSEAM

Inner Leg Measurement



The distance between the lowest part of the trunk and the soles of the feet measured when standing upright with the feet slightly apart and the weight of the body evenly distributed on both legs.